SB-SV Installation

Before beginning the installation please verify the operation of the brake lights.



STEP 1:

Per the owner's manual, remove the rear seat compartment to expose the 3-pin nylon connector.

STEP 2:

Disconnect this 3-pin connector.



E93 L CITY World Vizi-tec.com Characteristics of the Company of th

STEP 3:

Plug the SB-SV unit in series between the 3-pin stock connector. The connector are keyed such that it can only be installed one way.

Tuck and secure the SB-SV unit with supplied tie-wraps and doubled-sided tape as shown. (See Datasheet for more installation help). Test for functionality.

Ride it, and tell all your friends about us!

